




FVN62-3012-UNS TORINO

INSTALLATION GUIDE

CONTENTS:



Cabinet	(FCB62-3012)	PAGE 3
Sink	(FVS6230)	PAGE 4
Mirror	(FMR6230)	PAGE 2




FVN62-3012-UNS
TORINO
INSTALLATION GUIDE




Mirror




Vanity Front




Vanity Back




TOOLS FOR ASSEMBLY




Side Cabinet Front



Side Cabinet Back




MIRROR INSTALLATION




DRAWER REMOVAL & INSTALLATION



REMOVAL



INSTALLATION




1 Install leg




2 Remove drawer

3 Install cabinet

IMPORTANT: Consult an expert for the proper screws/bolts to use when attaching to various wall constructions. Screws provided do not attach to all wall construction types.




4 Install top panel





5 Remove side cabinet drawer

6 Install side cabinet




7 Install side cabinet top panel






FVN62-3012-UNS TORINO INSTALLATION GUIDE



P-TRAP & POP-UP


INSTALLATION INSTRUCTIONS

Your item may appear slightly different from the illustration.




POP-UP INSTALLATION

FOR SINKS WITHOUT OVERFLOW




OR

FOR SINKS WITH OVERFLOW



P-TRAP INSTALLATION

1. Install tail pipe (**G**).



2. Install P-trap (**J**).

