

LIVING DISTRICT


Collection: Ezra












Installation manual for:

LD7304W29CH W28.7"*E7.5" H7.6" L4

Installation instructions:

1. Black wire from ceiling(junction box) attaches to "L" wire from the fixture.
 2. White wire from ceiling(junction box) attaches to "N" wire from the fixture.
 3. "E" wire from the fixture is attached to the mounting bracket and an additional "E" wire from the mounting bracket must be secured to the junction box.
 4. Secure mounting bracket to the junction box.
 5. Insert the mounting bracket screw(P2) into the mounting bracket (P1).
 6. Using the screw(P3) to lock the lamp body onto the mounting bracket (P1) on the wall.
 7. Install E12 light source.(Bulbs not supplied).
 8. Twist the glass shade(P11) onto the lamp body.
- The end!



Part Number	Part	Picture	Description	Qty
MB7S19	P1		Mounting bracket L15"*W4.7"	1
	P2		Mounting bracket screw	2
P-LD7304W29CH-1	P3		Screw	2
	P4		Backplate (L28.7"*W5.5")	1
	P5		Aluminum ring Φ2"*H0.4"	4
	P6		E12 holder	4
	P7		UL18#Ground wire,L9.8"	1
	P8		UL18#,L8"	1
GS7R02CH	P9		Aluminum ring Φ2.7"*H0.3"	4
	P10		Plate Φ1.8"*T0.1"	4
	P11		Glass shade Φ5.9"*H5.7"	4

"L" = Hot wire

"N" = Neutral wire

"E" = Ground wire