




Installation Manual - WLM.1900

1/2" Wall Mount Valve With 2- Handles

Use With Trims Ending in *1900 / *1950 / *2450



BEFORE YOU BEGIN

- You must observe all local plumbing laws and codes.
- Do not install this valve if it does not meet local plumbing codes.
- Shut off the main water supply.

TABLE OF CONTENTS

• Operating Specifications	1
• Valve Installation And Tolerance	
• Cut-Out Dimensions	1
• Rough In Specification	2
• Connecting The Supply & Output Lines	3
• Flushing The Valve / Replacing Volume Control Cartridge	4
• Installing The Trim	5
• Installing The Extension Kit	8
• Cartridge Maintenance	9

NOTICE TO HOMEOWNER

- We recommend that this product is installed by a qualified professional plumber.
- Please check this product immediately to ensure that it has not been damaged and is complete. Before installation, please make sure this product is the correct model and you have all the parts required for installation and use.
- Please flush the water system to ensure that no metal swarf, solder, and other impurities can enter the product.
- Turn off water supply before commencing work.
- Please read these instructions carefully and retain for future reference.

OPERATING SPECIFICATIONS

WATER TEMPERATURE



This product is to be used with water at a temperature range of 40°F - 120°F ONLY!

WATER PRESSURE




This product is to be used with a water pressure range of 15 PSI to 80 PSI ONLY

If water pressure is greater than 80 PSI install a pressure reducing valve (PRV)

This valve meets or exceeds ANSI A112.18.1 and ASSE 1016

This valve is certified by IAPMO

CUT OUT DIMENSIONS



Isenberg's wall mount two handle lavatory valves does not come with a mud guard. It is essential to review the cut-out dimensions shown on the left so that the proper hole sizes are cut-out in the finished tile.

Wall Cut Out Dimensions From **Center Point** of Valve:

WLM.1900


3 equal holes of 1.3" / 33 mm

Y = 102mm / 4.2"

ROUGH IN SPECIFICATION

Maximum = 3,15"

Minimum = 2,15"




The distance between back of the valve to the finished tile surface should be between 2.15" and 3.15" inches.


If valve is installed too deep into the wall, extensions are available.




CONNECTING THE SUPPLY & OUTPUT LINES



Fix Valve on wooden plank




Level Valve



Attach Hot/Cold Supply Lines

FLUSHING THE VALVE / REPLACING THE VOLUME CARTRIDGE



In order to clear dirt in the lines - you must flush the valve before the wall is closed and water is turned on for the first time.


1) Remove volume control cartridge by turning with a spanner

4) Turn on water supply and let water flow removing any dirt in the lines.


INSTALLING THE TRIM - TRIM PLATE SIZE AND SHAPE MAY VARY - ILLUSTRATION ONLY




Insert stem extension on hot and cold handle and secure using provided screws



Insert handle circular trims and output spout connector




Insert flange



Secure with a small amount of clear silicone on the back end of the flange


INSTALLING THE TRIM - TRIM PLATE SIZE AND SHAPE MAY VARY - ILLUSTRATION ONLY




Insert handle and long hex screw



Tighten long hex screw to secure handle




Insert handle rod and tighten




Insert spout

INSTALLING THE TRIM - TRIM PLATE SIZE AND SHAPE MAY VARY - ILLUSTRATION ONLY




Tighten hex screw to secure spout




This photo shows a completely installed trim


INSTALLING EXTENSIONS TO THE VALVE - OPTIONAL




Remove existing handles and trim on handles



Install volume stem extension kit, tighten screws and then install longer trim piece




Remove existing spout piece



Insert longer spout extension piece

INSTALLING EXTENSIONS TO THE VALVE - OPTIONAL



All extension trim pieces installed shown in this illustration

CARTRIDGE CLEANING & MAINTENANCE

Volume Control Cartridge:

